




AC Circuit Frequency Response (Chapter 14)

Three Phase circuit


- In this chapter, circuits connecting balanced three-phase sources and balanced three-phase loads are analyzed.
- The balanced three-phase sources are three voltages with the same amplitude and frequency, but three different phases separated by 120°.
 The sources can be arranged in a wye (Y) shape or a delta (Δ) shape.
- The balanced loads refer to three loads with identical impedances and also can be arranged in a Y or Δ shape.
- There are four combinations in connecting three-phase sources and three-phase loads.
- These are Y-Y connection, Y- Δ connection, Δ Δ connection, and Δ -Y connection.
- The delta connected sources have equivalent wye connected sources, and vice versa.
- The delta connected loads have equivalent wye connected loads, and

UNIVERSITY OF WOLLONGONG IN DUBAI

- The three voltage sources can be connected in Y shape (wye shape) or Δ shape (delta shape),
- The three voltages Van, Vbn, and Vcn in the Y-connected source are called phase voltages. Van + Vbn + Vcn = 0.
- The voltages between the lines, Vab, Vbc, and Vca, are called line voltages.




■ The three voltage sources can be connected to three phase load impedance





- If the 3-phase system is balanced
- The neutral wire doesn't carry any current and it can be omitted from the circuit





■ Note that there is the following relationship between phase voltages and line-line voltages:

$$E_{ab} = \sqrt{3}E_{an} \angle 30^{\circ}$$

$$E_{bc} = \sqrt{3}E_{an} \angle (30\text{-}120)^{\circ}$$

$$E_{ca} = \sqrt{3}E_{an} \angle (30\text{+}120)^{\circ}$$

Assuming the phase 'a' as our reference angle.



7


■ Verify the relation between the line to line voltage and phase voltage



$$I_{AB} = \sqrt{3}E_{an} \angle 30^{\circ} / Z_{\Delta}$$

$$I_{BC} = \sqrt{3}E_{an} \angle (30 - 120)^{o} / Z_{\Delta}$$

$$I_{CA} = \sqrt{3}E_{an} \angle (30 + 120)^o / Z_{\Delta}$$






■ We have the following relation between line-line current and phase currents:


$$I_a = \sqrt{3}I_{AB} \angle -30^{\circ}$$


 $I_b = \sqrt{3}I_{BC} \angle -30^{\circ}$
 $I_c = \sqrt{3}I_{CA} \angle -30^{\circ}$






Delta connected load could be presented as Y connected load as shown in the figure below:








The 3-phase system can supply two loads, one is delta connected and one is wye connected








Three Phase: balanced Circuit

■ A balanced Y-connected source connected to the balanced Y-connected load is shown












■ In the balanced Y-Y connection shown in Figure 12.6, let the magnitude of the line voltages be VL = 880 V (rms), the load impedance per phase be ZY = 50 + j25 Ohms, and the phase angle of Van be 0°. Find the phase voltages, the line currents, and the line voltages. Also, find the complex power, apparent power, average power, reactive power, and power factor of the load.





Three Phase: Example 1 Solution



- A balanced three-phase Y-connected generator with a positive sequence has an impedance of 0.2 + j0.5 Ohms per phase and an internal voltage of 120 V/phase. The generator feeds a balanced three-phase Y-connected load having an impedance of 39 + j28 Ohm per phase. The impedance of the line connecting the generator to the load is 0.8 + j1.5 Ohm/phase. The a-phase internal voltage of the generator is specified as the reference phasor.
- A) construct the a-phase equivalent circuit of the system
- Calculate the three line currents
- Calculate the three-phase voltage at the load
- Calculate the line voltage at the terminal of the load
- Calculate the phase voltage at the terminal of the generator
- Calculate the line voltage at the terminal of the generator



Three Phase: Example 2 Solution




Three Phase: Complex Power

- In a three-phase system, the total power is the sun of the three-phase power.
- Under this section, the materials cover the followings
- A) Complex power S
- B) Real Power P
- C) Reactive Power Q

$$\blacksquare S = 3V_{\emptyset}I_{\emptyset}^*$$

$$\blacksquare P = S \times Pf$$

$$Q = S \times \sin(\theta)$$





■ In a balanced three-phase system, the source has an abc sequence, is Y-connected, and Van = 120/20° V. The source feeds two loads, both of which are Y-connected. The impedance of load 1 is 8 + j6 Ohms/phase. The complex power for the a-phase of load 2 is 600/36° VA. Find the total complex power supplied by the source.



Three Phase: Example 3 Solution




■ A balanced three-phase source is supplying 60 kVA at 0.6 lagging to two balanced Y-connected parallel loads. The distribution line connecting the source to the load has negligible impedance. Load 1 is purely resistive and absorbs 30 kW. Find the per-phase impedance of Load 2 if the line voltage is 120 V5 V and the impedance components are in series.



Three Phase: Example 4 Solution



■ The impedance Z has the following value: 100-J75 Ohm. Finds the line current I_{aA} , I_{AB} and I_{bc} .





Three Phase: Example 5 Solution



- A balanced, three-phase circuit is characterized as follows:
- Y-A connected;
- • Source voltage in the c-phase is 20 and 9 0 ° V;
- • Source phase sequence is abc;
- • Line impedance is 1 + j3 Ohms/Phase
- • Load impedance is 117—j99 Ohms/Phase.
- a) Draw the single-phase equivalent for the a-phase.
- b) Calculate the a-phase line current.
- c) Calculate the a-phase line voltage for the three-phase load.



Three Phase: Example 6 Solution

